


Follow instructions on reverse side BEFORE POWERING UP THE DEVICE

1 PLUG INTO DESIRED LOCATION TO POWER




POSSIBLE LOCATIONS:

LIVING ROOM
KITCHEN

HOME OFFICE
CLOSET

2 CONNECT CABLE OR JOIN WPS

IF ETHERNET: ATTACH ETHERNET TO HELIX & ROUTER THEN PLUG INTO DESIRED LOCATION



IF WIFI: PRESS WPS BUTTONS ON BOTH HELIX AND CUSTOMER'S ROUTER

3 CHECK LEDs

- POWER: GREEN BLINKS RAPIDLY
- NETWORK CONNECTIVITY: GREEN WHEN CONNECTED
- CENTRAL STATION CONNECTIVITY: GREEN WHEN CONNECTED
- PLATFORM CONNECTIVITY: GREEN WHEN CONNECTED
- ARMING STATUS: GREEN: DISARMED RED: ARMED
- TROUBLE-AMBER: SYSTEM TROUBLE IS DETECTED
- RF ACTIVITY: BLINKS RAPIDLY WHEN ANY SENSORS ARE COMMUNICATING UNUSED
-

4 DOWNLOAD AND USE APPS FOR INSTALL AND CONTROL

